Change Windows MAC addresses

Disclaimer

- You do this at your own risk.
- Make sure you understand the consequences of what you are doing and are legally authorized to make changes



Change Windows MAC Address

- Want to watch a YouTube video?
 - http://bit.ly/changemacwindows



Change Windows MAC Address

- Methods:
 - See if you can change the MAC address using the easy way first
 - 2. If not, use the Windows Registry Editor




Method 1

• This is the easy way, but not all network cards support this.




- Right click on Windows
 Start button
- Click Device Manager







Click Network adapters




- Right click the Network
 Adapter you want to change
- Click Properties



- Select the Advanced Tab
- Click Locally Administered Address



- Specify the new MAC address
- Click OK
- If the MAC address change fails try setting the second character to 2 or 6 or A or E






Verification Option 1

 Use a command prompt command to verify the MAC address change




Verification Option1: Part 1

Open a command prompt



Verification Option 1: Part 2

 Use the getmac command to verify that the MAC address has changed






Verification Option 2


Use the GUI to verify the MAC address change




Open Control Panel




- Select Network and Internet
- Select Network and Sharing Center



- Click Change adapter settings
- Double Click Network Card you changed




Click Details





Verify new MAC address






Method 2

- This is the hard method.
- Uses the Windows Registry
- Be careful!



Open a command prompt



 Use the getmac command to find the MAC address and Transport Name

```
C:\Users\david>getmac
```

C:\Users\david>

- Open the Registry Editor
- Go to this key:
 - HKEY_LOCAL_MACHINE/SYSTEM/ControlSet001/Control/Class/ {4D36E972-E325-11CE-BFC1-08002BE10318}
- Multiple folders are displayed:
 - 0000, 0001, 0002 etc.
- Search for your first portion of your NIC Identifier from the getmac command:
 - Example: 79361F3E
- Verify that the NetCfgInstanceId is the same as the value shown in the getmac command

- Right click and create a string value with the name NetworkAddress
- Specify your MAC address
 - If the MAC address change fails try setting the second character to 2 or 6 or A or E
- Check if the changes work
 - Disable and then re-enable the network card or reboot the computer




Verification Option 1

 Use a command prompt command to verify the MAC address change



Verification Option 1: Part 1

Open a command prompt



Verification Option 1: Part 2

 Use the getmac command to verify that the MAC address has changed

```
Command Prompt
C:\Users\admin>getmac
Physical Address
                    Transport Name
                                ip {5FC0B57A-F04B-438C-BE1F-9BC19DF366F7}
00-11-22-33-44-55
                    Media disconnected
7C-DD-90-1F-77-CE
                     \Device\Tcpip {72F83914-E4C3-4EE8-8D10-F890EDCA5773}
02-00-4C-4F-4F-50
                     \Device\Tcpip_{5E816F1E-28CF-4466-B9DA-8DFA39A2E627}
0A-00-27-00-00-05
C:\Users\admin>
```




Verification Option 2


Use the GUI to verify the MAC address change




Open Control Panel




- Select Network and Internet
- Select Network and Sharing Center



- Click Change adapter settings
- Double Click Network Card you changed




Click Details





Verify new MAC address





Change Windows MAC

addresses